



Quick Install Guide

This Quick Install Guide is Applicable for the InnovaSonic® 203.

A copy of this Quick Install Guide and the [203 product instruction manual](#) are included on the product information CD included in your shipment. The information is also available for [download](#).

Keypad Functions

The InnovaSonic 203 keypad offers 16 tactile keys with 12 dual-function keys for easy operation of the menu system and setup. The quick-key functions are enabled by pressing directly on the related key. You do not need to press the key to enable quick-key functions. For example, pressing will show maximum flow rate and pressing will show totalized flow. See the [203 Instruction Manual, Chapter 2](#) for detailed explanations of all they keys.

Follow these guidelines when using the InnovaSonic 203 menu system:

- Keys to are the menu codes to input information required for flow measurement.
- Push to backspace or delete characters to the left.
- Use and to return to the previous menu or to open the next menu. These keys act as "+" and "-" functions when entering numbers.
- is used to select two digit numbers from the menu. To enter a selected menu, press key first then press your selected digit numbers. Hit enter to save the selected menu. For example, to input a pipe outside diameter, press keys, where "11" is the window ID to display the parameter for pipe outside diameter.



Figure 1. 16 Tactile Keys With 12 Dual-Function Keys

Installation Steps

1. Open the hinged top cover of the electronics (See Figure 2). Make the minimum connection which is the DC power, downstream transducer, and upstream transducer. Figure 2 also shows the relay, OCT, 4-20 mA output and RS-485 (standard option) communication connections. Note: On the meter, the upstream transducer cable is coded red and the downstream is blue.






Figure 2. Transmitter Connections

2. Select the mounting location and method depending on the pipe diameter.



V Method: Pipes 50mm to 400mm (2 inches to 16 inches)...signal bounces off pipe wall



Z Method Pipes: 400mm to 1200mm (16 inches to 48 inches)...signal is directly transmitted

3. Select the measurement site on a straight section of pipe with 10D (10 pipe diameters) upstream and 5D downstream (See Figure 3). The transducers are usually installed at the 3 o'clock and 9 o'clock positions on the pipe. Avoid installation at 6 o'clock and 12 o'clock positions (See Figure 4).




Figure 3. Upstream and Downstream Pipe Diameter Example




Figure 4. Optimal Transducer Installation Location

4. Power up the electronics with DC power.

5. Enter the pipe set up parameters.

Note:

- The distance (spacing) between the upstream and downstream transducers is calculated using the pipe parameters you enter.
- The meter accuracy is only as good as the parameters you enter.
- Metric or English measuring units are selected in Menu 30.

Step 1. Pipe Outer Diameter

Press **Menu** **rate** **1** **rate** **1**, then **Enter** to enter the pipe outside diameter. Press **Enter** to accept the changes.

Pipe Outer Diameter
200 mm

Step 2. Pipe Wall Thickness

Press **Menu** **rate** **1** **total** **2**, then **Enter** to enter the pipe wall thickness. Press **Enter** to accept the changes.

Pipe Wall Thickness
6 mm

Step 3. Pipe Material

Press **Menu** **rate** **1** **cool cap.** **4** then **Enter**. Use the **^/+** or **v\-** keys to select pipe material from the drop-down list, and then press the **Enter** key to accept.

Pipe Material [14
0. Carbon Steel

Step 4. Transducer Mounting Methods

Press **Menu** **total** **2** **cool cap.** **4** then **Enter**. Use the **^/+** or **v\-** keys to select transducer-mounting method from the drop-down menu, and then press the **Enter** key to accept.

Transducer Mounting
0. V

Step 5. Transducer Spacing

Press **Menu** **total** **2** **heat cap.** **5** to see the calculated transducer spacing. Accurately install the transducer according to the displayed transducer mounting spacing and the selected mounting method.

Transducer Spacing
159.86 mm

- Use the calculated Transducer Spacing for transducer spacing during installation.




Figure 3. Pipe Orientation and Preparation (Cleaning)




Figure 4. Applying Coupling Grease to Transducers



Figure 5. Mounting Transducers

- Verify the transducers mounting and signals. The pipe must be 100% full of fluid before proceeding.

Step 1. Signal Strength & Quality

Press **signal 9** or **Menu signal 9 zero 0** for the signal strength and quality of the installed transducers. Acceptable signals would be UP and DN signal strength of at least 60 and the signal quality (Q) of at least 50.




Strength+Quality [90
UP:00.0 DN:00.0 Q=00


Step 2. TOM/TOS

Press **Menu signal 9 rate 1** to displays the TOM/TOS. This is the ratio of the measured transit time over the calculated transit-time. An acceptable ratio is $100 \pm 3\%$. If this is out range, check the spacing, pipe parameters, and fluid sound velocity. Flow measurements may not be accurate if this is out range.


TOM/TOS* 100 [91
0.0000%


Step 3. Flow Rate Display


To read the flow rate, press   . You should see the flow rate, the flow units, *R (Normal Operation code), and the Net Totalizer count. If you do not see the R* code, go back and check the signal strength, Q, and TOM/TOS. Other codes are explained in the [203 Instruction Manual, Chapter 2](#).




Flow 0.1154 m³/h * R
NET 0 x 1m³


8. Press the  to show various flow information. See below examples.

Press  key once to show the maximum flow rate.





FLOW Max.
0.0000 GAL/m

Pressing the  key a second time will show the minimum flow rate.





FLOW Min.
0.0000 GAL/m

Press the  key a third time to view the average flow rate.



FLOW Avg.
0.0000 GAL/m

Press  a fourth time to view the current flow rate.



FLOW Present.
0.0000 GAL/m

Limited Warranty Policy - Register Online

All Sierra products are warranted to be free from defects in material and workmanship and will be repaired or replaced at no charge to Buyer, provided return or rejection of product is made within a reasonable period but no longer than one (1) year for calibration and non-calibration defects, from date of delivery. To assure warranty service, customers must register their products online on Sierra's website. Online registration of all of your Sierra products is required for our warranty process. Register now at www.sierrainstruments.com/register. Learn more about Sierra's warranty policy at www.sierrainstruments.com/warranty.

NOTE: The information presented is for a quick start-up for the InnovaSonic 203. Other parameters are referenced in the 203 Instruction Manual.