

Note:

The Palm Treo, which is now being used as the interface on the model 210 ultrasonic will not completely power down unless you close the 210 application.

To do this press the Home button, which is the house icon. This will close the application and show a list of applications. You may then press the red power button on the Treo to turn off the Treo.

To power up the Treo, press the red power button, then press the Home button. Choose the 210 application. The 210 application will start.

Remember to always power up the 210 flow meter first and power it down last.

Move around the touchscreen

To move around the touchscreen on your Treo, you can use the 5-way navigator, or you can tap items on the touchscreen with the stylus. The 5-way includes the following buttons:

